

## Re & Re a Frameless Window

Start by removing the two lower blind brackets.



Next remove the blind valence. Use a flat screw driver to pop the snap cap off to reveal the screw.



To remove the blind, swing the blind up and away from the window to reveal the anchor clips. Push the metal tab toward the trailer wall while twisting the head rail down. These clips hold the blind tight and this step can be a struggle.



Next remove all of the screws holding the trim ring in place and then remove the trim ring.



Remove the knob.



Then have someone of the exterior to hold the window while you pop it loose from the inside. Start at one bottom corner and push on the window frame to try to break the seal between the window and the trailer. Once you have one corner loose, pop the other bottom corner loose. If there is sealant across the top of the window, you will need to use an exacto knife to cut the seal. Then continue to remove the window.



See photo to attach gasket to new window. Start seam at the bottom of the window, keeping the gasket a little less than 1/8" from the edge of the frame all the way around.



To install the new window, have someone hold the window in place from the exterior and install 2-3 screws. Only install the screws about half way, then go outside to ensure the window is installed squarely. Once you are happy with the placement, continue to install the remaining screws. You can fully seat all of the screws at this point.