

Optional RV/Marine Winterization Instructions

If your Splendide is installed in a vehicle and you are currently pumping antifreeze through your fresh water system, you can follow these steps to winterize your washer-dryer (if not, skip to steps below):

Start

1. With machine power OFF, turn **WASH TEMP** knob to '**HOT**';
2. Advance **Cycle Selector** to **position '3'**;
3. Press **ON/OFF** button, then press **START**. Let machine fill until the drum turns (could take up to 1 to 2 minutes);
4. Press **ON/OFF** button to turn power OFF;
5. Advance **Cycle Selector** to '**Spin**';
6. Press **ON/OFF** button, then press **START**.

END

7. After letting antifreeze drain completely from drum, press the **ON/OFF** button to turn power OFF. **FINISHED**.

To winterize your washer-dryer installed in a vehicle,

Start

1. With washer-dryer power OFF, pour ½ quart of RV-type antifreeze into washer drum;
2. Close door. Advance **Cycle Selector** to '**Spin**';
3. Press **ON/OFF** button, then press **START**. let the washer-dryer run for 1 to 2 minutes;
4. Press **ON/OFF** button to turn power OFF.

END

5. Unplug washer-dryer from electrical outlet (or disconnect power);
6. Turn water supply faucets OFF. Disconnect inlet hoses from faucets;
7. Drain remaining water from the hoses. **FINISHED**.

To use your washer-dryer again,

Start

1. Reconnect water inlet hoses to corresponding HOT/COLD faucets. Turn faucets ON. *NOTE: Check water inlet hoses and pump periodically (see Users Guide);*
2. Plug washer-dryer into appropriate electrical outlet (*see Users Guide*) - **OR** reconnect power supply;
3. With washer-dryer power OFF, pour 1/2 TBSP. of powder detergent (or liquid equiv.) into **compartment '2'** inside **Dispenser Drawer**;
4. Advance **Cycle Selector** to **position '9'**;
5. Press **ON/OFF** button, then press **START**.

END

6. Allow machine to run through the complete cycle to clean out any remaining antifreeze. **FINISHED**.