




Pump Repair Kits 2088/2093 Series



Name	Model # OEM/Aftermarket	Pumphead Kit 1	Lower Housing 2	Valve Assembly 3	Check Valve 4	Switch & Upper Housing 5	Motor 6
Standard	2088-423-344 2088-423-344	94-236-03 94-236-03	94-238-04 94-238-04	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-006-07 77-006-07
Standard 24 VDC	2088-743-244 2088-573-354	94-236-03 94-236-03	94-238-04 94-238-04	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-011-07 77-011-07
Silencer™	2093-224-313 2093-224-313	94-236-03 94-236-03	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-012-07 77-012-07
Deluxe	2088-733-244 2088-433-344	94-236-03 94-236-03	94-238-04 94-238-04	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-001-07 77-001-07
Premium	2088-712-244 2088-414-934	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-002-07 77-002-07
Standard Blaster™	2088-732-244 2088-534-344	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	11-173-06 11-173-06
Standard Blaster™ (24 VDC)	2088-752-244 2088-574-344	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	11-187-06 11-187-06
ProBlaster™	2088-732-234 2088-534-944	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-001-07 77-001-07
Pro Baitmaster™	2088-721-234 2088-414-734	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-002-07 77-002-07
Pro Baitmaster™ (24VDC)	2088-762-234 2088-574-734	94-236-14 94-236-14	94-238-03 94-238-03	94-232-06 94-232-06	94-237-00 94-237-00	94-231-10 94-231-10	77-004-07 77-004-07

Note:

-Drive Assembly & Diaphragm are included in lower Housing Kit # 2

Updated: 5/28/09